

## ***Synth Controller manual addendum for edition 'K3' for Kawai K3/K3m***

If your K3 does not want to respond to the controller:

- a) are the midichannels of synth and controller identical?
- b) is the Master-Parameter 42 set to 6?